

TRANSIT PARTS



Fleet Component and Parts Specialist



TABLE OF CONTENTS

BRAKES..... 3

COOLING..... 4

DOORS..... 6

ELECTRICAL 7

ENGINE..... 9

EXHAUST..... 10

FUEL SYSTEM..... 11

GLASS AND BODY 11

LIGHTING 14

MIRRORS AND CAMERAS 14

STEERING 15

SUSPENSION 16

TRANSMISSION..... 18

WHEELS AND TIRES..... 18

WINDSHIELD WIPERS..... 19

ACCESSORIES20

INDEX.....23

BRAKES

CK4Z2001A	CK4Z2200B	GU2Z2V200D	84260A
			
BRAKE PADS (FRONT)	BRAKE PADS (REAR)	BRAKE PADS (REAR)	BRAKE HARDWARE KIT

CK4Z2C026C	CK4Z1125C	CK4Z2B120B	CK4Z2B121B
			
ROTOR (REAR)	ROTOR (FRONT)	CALIPER (FRONT - RIGHT)	CALIPER (FRONT - LEFT)

CK4Z2552C	CK4Z2553C	BK2Z2C204A	CK4Z2A635V
			
CALIPER (REAR - RIGHT)	CALIPER (REAR - LEFT)	ABS SPEED SENSOR	PARK BRAKE CABLE (RIGHT)

CK4Z2A635Y	CK4Z2078A	CK4Z2282A	BK2Z2853A
			
PARK BRAKE CABLE (LEFT)	HYDRAULIC BRAKE HOSE (FRONT)	HYDRAULIC BRAKE HOSE	INTERMEDIATE PARK BRAKE CABLE

BRAKES

CK4Z2140A	CK4Z2063A	9N5Z2162A	CK4Z2005B
			
MASTER CYLINDER	MASTER CYLINDER RESERVOIR	MASTER CYLINDER RESERVOIR CAP	POWER BOOSTER

W711141S442

FRONT ROTOR HUB BOLT

COOLING

CK4Z8005B	RAD78	CK4Z8260B	CK4Z8286B
			
RADIATOR	RADIATOR (3.5L & 3.7L)	RADIATOR HOSE (UPPER)	RADIATOR HOSE (LOWER)

DG9Z8100A	BK2Z8A080B	CK4Z8C607D	BL3Z8592C
			
RADIATOR CAP	COOLANT RESERVOIR	COOLANT MOTOR AND FAN ASSEMBLY	COOLANT THERMOSTAT HOUSING

COOLING

BL3Z8575A	BR3Z8255A	BR3Z8501N	BR3Z8507C
			
THERMOSTAT	THERMOSTAT GASKET	WATER PUMP	WATER PUMP GASKET

CK4Z19712B	FO3030246	9T1Z8005A
		
CONDENSER ASSEMBLY	A/C CONDENSOR	RADIATOR

DOORS

BK3Z1542900A	BK3Z1542900G	BK3Z6126800L	BK2Z6122600A
			
DOOR HINGE ASSEMBLY (REAR DOOR - UPPER)	DOOR HINGE - PASSENGER SIDE (LOWER - REAR) (UPPER - RIGHT)	DOOR HINGE (PASSENGER SIDE)	DOOR HANDLE (INTERIOR FRONT - RIGHT)

BK3Z1525028C	BK2Z1525000A	EK4Z1525028A	BK2Z6126604A
			
SLIDING DOOR ROLLER HINGE (UPPER - RIGHT)	SLIDING DOOR ROLLER HINGE (LOWER - RIGHT)	SLIDING DOOR ROLLER HINGE (CENTER - RIGHT)	SLIDING DOOR HANDLE (OUTSIDE)

CV6Z5422404DA	BK2Z6122601AA	BK2Z6126680A	CK4Z6122666A
			
DOOR HANDLE (OUTSIDE) (LEFT AND RIGHT)	DOOR HANDLE (INTERIOR REAR - LEFT)	DOOR HANDLE (INTERIOR REAR - LEFT)	SLIDING DOOR HANDLE (INSIDE)

HK3Z6144100A	BK3Z6123500B	AM5Z17218B08A	BK2Z14028AA
			
DOOR CHECK (REAR - LEFT AND RIGHT)	DOOR CHECK (FRONT - LEFT AND RIGHT)	DOOR HANDLE BEZEL (FRONT - LEFT OR RIGHT)	DOOR LOCK SWITCH (FRONT - LEFT AND RIGHT)

DOORS

CK4Z61219A65J	CK4Z61264A00D	EK4Z6123200B	EK4Z6123201A
			
DOOR LATCH ASSEMBLY (FRONT - LEFT AND RIGHT)	SLIDING DOOR LOCK ACTUATOR (PASSENGER SIDE)	WINDOW REGULATOR (PASSENGER SIDE)	WINDOW REGULATOR (DRIVER SIDE)

3T1Z1525001A	HK3Z61441A14B
	
SLIDING DOOR ROLLER BRACKET (LEFT SIDE)	DOOR CHECK COVER

ELECTRICAL

8S4Z10346A	CK4Z11002C	6CPZ5423395C	6CPZ9923394B
			
ALTERNATOR	STARTER (3.7L)	POWER WINDOW MOTOR (DRIVER SIDE)	POWER WINDOW MOTOR (PASSENGER SIDE)

ELECTRICAL

7T4Z12029E	AA5Z6C315A	AT4Z6B288A	BL3Z6B288C
			
IGNITION COIL	CRANKSHAFT POSITION SENSOR	CAMSHAFT SENSOR	CAMSHAFT POSITION SENSOR (INNER)

7T4Z12A699A	BK3Z2C204C	9L8Z6G004E	DG9Z11572A
			
IGNITION KNOCK SENSOR	WHEEL ASSEMBLY SENSOR (REAR)	COOLANT TEMPERATURE SENSOR	IGNITION SWITCH

BK3Z14529B	CK4Z13832A	CK4Z19980A	CV6Z11654L
			
DOOR WINDOW SWITCH (DRIVER SIDE)	HORN	DASH CONTROL UNIT (W/O PTC HEATER)	HEADLIGHT SWITCH

F1FZ13341A	SW6559	BK2Z14526B	JK4Z15604A
			
TURN SIGNAL COMBO LEVER SWITCH	BRAKE LIGHT SWITCH	MAXI FUSE ASSEMBLY (60/80/100/200 AMP)	JUNCTION BLOCK (PASSENGER COMPARTMENT)

ELECTRICAL

FB5Z9F472A	GK4Z9F472A	GK4Z9G444A	GK4Z9G444B
			
OXYGEN SENSOR (FRONT - RIGHT)	OXYGEN SENSOR (FRONT - LEFT)	OXYGEN SENSOR (REAR - LEFT)	OXYGEN SENSOR (REAR - RIGHT)

ENGINE

BR3Z9448C	ML3Z6675P	9L8Z6730A	FL-500S
			
EXHAUST MANIFOLD GASKET	OIL PAN (LOWER)	OIL DRAIN PLUG	OIL FILTER (3.7L)

PH500	EP5Z6766A	CK4Z9601A	AT4Z9H486A
			
OIL FILTER	OIL FILLER CAP	AIR FILTER (3.7L)	INTAKE MANIFOLD GASKET

BR3Z6584B	BR3Z6584B	BL3Z8620C	DK4Z8620B
			
VALVE COVER GASKET (RIGHT SIDE)	VALVE COVER GASKET (LEFT SIDE)	SERPENTINE BELT (LEFT SIDE)	SERPENTINE BELT (RIGHT SIDE)

ENGINE

CK4Z6096C	XW4Z6700AA	CK4Z9C675A	CK4Z9C623C
			
ENGINE MOUNT (FRONT)	CRANKSHAFT SEAL	AIR INTAKE HOSE	AIR CLEANER INTAKE TUBE

8V2Z12B579A	BL3Z6A666AA	GC3Z9278A	SP520A
			
MASS AIR FLOW SENSOR	PVC VALVE	OIL PRESSURE SENSOR	SPARK PLUG (3.7L)

Also Available

PART NUMBER	DESCRIPTION
BL3Z12029C	DIRECT IGNITION COIL

EXHAUST

CK4Z5202S	CK4Z5230E	GK4Z5F250H	GK4Z5F250J
			
EXHAUST TAIL PIPE	EXHAUST MUFFLER	CATALYTIC CONVERTER (RIGHT)	CATALYTIC CONVERTER (LEFT)

FUEL SYSTEM

CK4Z9H307D	BR3Z9F593B	8G1Z9C385A	4L3Z9276AA
			
FUEL PUMP AND SENDER ASSEMBLY	FUEL INJECTOR	FUEL TANK LOCK RING	FUEL PUMP RING GASKET

AT4Z9E926B	FS19530
	
THROTTLE BODY AND MOTOR ASSEMBLY	WATER SEPARATOR FUEL FILTER

GLASS AND BODY

EK4Z5403100C	CK4Z17C897BA	FO1223124	CK4Z17C829AC
			
WINDSHIELD	GRILLE MOUNTING PANEL	GRILLE REINFORCEMENT MOUNTING PANEL	BUMPER FACIA (REAR)

CK4Z17F774DC	CK4Z17F774DD	BK3Z61278L01AA	BK3Z61278L01BC
			
REAR END BUMPER CAP (RIGHT)	REAR END BUMPER CAP (LEFT)	WHEEL MOLDING DEFLECTOR (FRONT - LEFT)	DEFLECTOR

GLASS AND BODY

BK3Z-6110176-AE	CK4Z8125A	W505434S439	CK4Z8327A
			
ROCKER PANEL MOULDING TRIM (RIGHT SIDE)	RADIATOR SUPPORT (LOWER - FRONT)	SUBFRAME BOLT (FRONT)	AIR DEFLECTOR (UPPER)

BK3Z16102A	BK3Z16102B	CK4Z16005A	CK4Z16006A
			
FENDER LINER (FRONT - LOWER - RIGHT)	FENDER LINER (FRONT - LOWER - LEFT)	FENDER (FRONT - RIGHT)	FENDER (FRONT - LEFT)

BK3Z16094A	BK3Z16095A	BK2Z16797A	BK3Z16796A
			
FENDER BRACE (FRONT - RIGHT)	FENDER BRACE (FRONT - LEFT)	HOOD HINGE (FRONT - LEFT)	HOOD HINGE (FRONT - RIGHT)

FO1236160	FO1236161	FO1042144	FO1043144
			
HOOD HINGE (LEFT)	HOOD HINGE (RIGHT)	BUMPER BRACKET COVER (LOWER - FRONT - LEFT)	BUMPER BRACKET COVER (LOWER - FRONT - RIGHT)

GLASS AND BODY

REPF480145	REPF480146	EK4Z6121411B	FO1006273
			
DOOR GLASS (PASSENGER SIDE) (83.2" ROOF)	DOOR GLASS (DRIVER SIDE) (83.2" ROOF)	DOOR GLASS (DRIVER SIDE)	BUMPER REINFORCEMENT (LOWER - FRONT)

FO1106380	FO1106379	FO1006271C	FO1253105
			
BUMPER REINFORCEMENT (REAR - MED/HIGH ROOF)	BUMPER REINFORCEMENT (REAR - LOW ROOF)	BUMPER REINFORCEMENT (UPPER - FRONT) CAPA	BUMPER BRACKET EXTENSION (FRONT - LOWER - RIGHT)

FO1042143	FO1043143	FK4Z16112C30AA	FO1068156
			
BUMPER BRACKET COVER (UPPER - FRONT - LEFT - PLASTIC)	BUMPER BRACKET COVER (FRONT - UPPER - RIGHT - PLASTIC)	CARGO MAT	LICENSE PLATE BRACKET (TEXTURED)

Also Available

PART NUMBER	DESCRIPTION
REPF480144	DOOR GLASS (FRONT - LEFT) (100.8"/110.2" ROOF)
REPF480143	DOOR GLASS (FRONT - RIGHT) (100.8"/110.2" ROOF)
FO1225246	RADIATOR SUPPORT REINFORCEMENT (PLASTIC W/
FO1252105	BUMPER BRACKET EXTENSION (FRONT - LOWER - LEFT)
68134792AA	ROOF SIDE PANEL RIGHT
BK3Z17C947H	BUMPER BRACKET (FRONT - LOWER - RIGHT)

LIGHTING

CK4Z13008E	CK4Z13008H	CK4Z13404G	CK4Z13405G
			
HEADLAMP ASSEMBLY (RIGHT)	HEADLAMP ASSEMBLY (LEFT)	TAILLAMP ASSEMBLY (REAR - RIGHT)	TAILLAMP ASSEMBLY (REAR - LEFT)

BK3Z13466A	9441732	92095787	9L2Z13466A
			
STOP LAMP ASSEMBLY (HIGH - CENTER)	HEADLAMP BULB (HIGH BEAM)	HEADLAMP BULB (LOW BEAM)	TURN SIGNAL BULB (REAR)

C7SZ13466B	YU5Z13466AD
	
SIDE MARKER (REAR)	AMBER BULB (FRONT TURN MARKER)

MIRRORS AND CAMERAS

EK4Z17682FA	EK4Z17683FA	EK4Z17683CB	BK3Z13B374D
			
MIRROR ASSEMBLY - POWER - RIGHT (HEATED - SIGNAL - MED/LOW ROOF)	MIRROR ASSEMBLY - POWER - LEFT (HEATED - SIGNAL - MED/LOW ROOF)	HEATED MIRROR - POWER (HEATED - SIGNAL - LEFT)	SIDE MIRROR LAMP (REAR - RIGHT - LONG/SHORT ARM)

MIRRORS AND CAMERAS

BK3Z13B375D	BK3Z-13B375-A	BK3Z-13B375-B	CK4Z17K707B
			
SIDE MIRROR LAMP (REAR - LEFT - LONG/SHORT ARM)	SIDE MIRROR SIGNAL LAMP (LONG ARM - LEFT)	SIDE MIRROR SIGNAL LAMP (LONG ARM - RIGHT)	MIRROR GLASS - POWER - LEFT (HEATED - UPPER)

CK4Z17K707C	CK4Z17682A	BK3Z-17K707-B	BK3Z-17K707-A
			
MIRROR GLASS - POWER - RIGHT (HEATED - UPPER)	MIRROR GLASS ASSEMBLY (OUTER - REAR)	MIRROR GLASS (LOWER - LEFT)	MIRROR GLASS (LOWER - RIGHT)

BK3Z17D742B	CK4Z17D742B	CK4Z19G490A	CK4Z19H511BA
			
MIRROR COVER (RIGHT - W/ LONG ARM)	MIRROR COVER - RIGHT (LONG ARM W/O SIGNAL - REAR)	BACKUP CAMERA	BACKUP CAMERA MOUNT

STEERING

CK4Z3E764C	YS4Z3A006BA	BK3Z3K186C	BK2Z3A130A
			
STEERING PUMP RESERVOIR	STEERING PUMP RESERVOIR CAP	STEERING KNUCKLE (LEFT)	OUTER TIE ROD

STEERING

BK2Z3280A	BK2Z3K661B	BK2Z18A047A	CK4Z3A674B
			
INNER TIE ROD	INNER TIE ROD BOOT	DUST SHIELD COVER BOOT	POWER STEERING PUMP

CK4Z3A212C	CK4Z3A719F	CK4Z3691B	CK4Z3A713H
			
PRESSURE HOSE ASSEMBLY	POWER STEERING PRESSURE HOSE	POWER STEERING COOLER LINE	POWER STEERING RETURN HOSE ASSEMBLY

CK4Z3504B	CK4Z3D746A
	
RACK AND PINION GEAR	POWER STEERING COOLING COIL

SUSPENSION

CK4Z3078A	CK4Z3079A	W718943S439	CK4Z5560R
			
CONTROL ARM (LOWER - RIGHT)	CONTROL ARM (LOWER - LEFT)	CONTROL ARM BOLT	REAR SPRING

SUSPENSION

FK3Z18125C	BK3Z5414B	BK2Z18198A	BK2Z18183B
			
REAR SHOCK ABSORBER	COIL SPRING INSULATOR (LOWER)	COIL SPRING INSULATOR (UPPER - FRONT)	SUSPENSION STRUT MOUNT (UPPER)

BK3Z5775Q	CK4Z18124E	BK3Z4730A	BK3Z5482A
			
LEAF SPRING BRACKET (REAR - FORWARD)	SUSPENSION STRUT (FRONT)	AXLE BEAM DAMPER (REAR)	STABILIZER BAR (FRONT)

BK2Z5776C	BK2Z5776D	BK2Z5K484A	BK3Z3050B
			
LEAF SPRING SHACKLE (REAR - LEFT)	LEAF SPRING SHACKLE (REAR - RIGHT)	STABILIZER BAR LINK (FRONT)	BALL JOINT (LOWER)

BK2Z3020A	BK3Z5484A
	
SUSPENSION STRUT BUMPER	BAR BUSHING (FRONT)

TRANSMISSION

CK4Z7A098A	CK4Z4782B	CK4Z6068E	MERCON LV
			
TRANSMISSION FILTER (6 SPEED)	DRIVE SHAFT COUPLING ASSEMBLY	TRANSMISSION MOUNT	TRANSMISSION FLUID (1 QT)

7L1Z4635B

UNIVERSAL JOINT

WHEELS AND TIRES

CK4Z1007B	ACPZ1012C	CK4Z1109A	9L3Z1A189A
			
STEEL WHEEL (6.5 X 16 D2XADO)	WHEEL LUG NUT	WHEEL HUB (REAR)	TPMS SENSOR

CK4Z1215E	BC3Z1244A	CC3Z1240A	BC3Z1243A
			
BEARING KIT (FRONT)	WHEEL BEARING (INNER - REAR)	WHEEL BEARING (OUTER CONE - REAR)	WHEEL BEARING RACE (OUTER - REAR)

WHEELS AND TIRES

CC3Z1239A	8C3Z1A124A
	
WHEEL BEARING RACE (INNER - REAR)	REAR AXLE HUB NUT

WINDSHIELD WIPERS

CV6Z16K624A	CV6Z17673A	F1FZ17A553A	EK4Z17528AA
			
WINDSHIELD FLUID LEVEL SENSOR GROMMET	WINDSHIELD FLUID PUMP GROMMET	WINDSHIELD WIPER SWITCH	WIPER BLADE (LEFT)

EK4Z17528CA	CK4Z17618A	KT1Z17632A	BV6Z17664D
			
WIPER BLADE (RIGHT)	WINDSHIELD FLUID RESERVOIR	WINDSHIELD FLUID RESERVOIR CAP	WINDSHIELD WASHER PUMP

CV6Z10D968A

WINDSHIELD FLUID LEVEL SENSOR

ACCESSORIES

63Y61	63Z21	64G01	64G11
			
LED NEAR FLOOD WORK LIGHT	LED LONG RANGE FLOOD WORK LIGHT	LED FAR FLOOD WORK LIGHT	LED NEAR FLOOD WORK LIGHT


68610	APS750	APS1250	PV100USB
			
PIGTAIL (FOR 63Z21 & 63Y61)	INVERTER CHARGER (750 WATT)	INVERTER CHARGER (1250 WATT)	COMPACT INVERTER (100 WATT W/ USB)

PV200CUSB	PV150	PV375	LB20-36-81
			
COMPACT INVERTER (200 WATT WITH USB)	COMPACT INVERTER (150 WATT)	COMPACT INVERTER (375 WATT)	BI-FOLD LOADING RAMP (36" X 81")

LB20-24-81	CVR151036-FRD	13193	75912
			
BI-FOLD LOADING RAMP (24" X 81")	LOADING RAMP (1500LBS - 10' X 36")	CLASS 3 TRAILER HITCH (2" RECEIVER)	CLASS 3 TRAILER HITCH (2" RECEIVER)

ACCESSORIES

415358-571501	401720	401727	415036
			
SHOCK ABSORBING BUMPER STEP (REAR)	DRIVER STEP BRACKET KIT	SIDE DOOR STEP BRACKET KIT	FRONT DOOR GRIP STEP (DRIVER AND PASSENGER)

415254	584026-570000	415026-570015	415026-570010
			
GRIP STEP (SIDE DOOR)	REAR BUMPER STEP (26" OMEGA - 2" RECEIVER)	REAR BUMPER STEP (26" W/6" DROP - 2" RECEIVER)	REAR BUMPER STEP (26" - 2" RECEIVER)

40450	6093	160012	160013
			
GRAB HANDLE (REAR DOOR)	UNIVERSAL GRAB HANDLE	SINGLE CARGO LAMP KIT	DOUBLE CARGO LAMP KIT

160014	050148	050145	050126
			
TRIPLE CARGO LAMP KIT	UPPER DRIVER SIDE PANEL (REAR - LOW ROOF)	UPPER PASSENGER PANEL (REAR - LOW ROOF)	UPPER DRIVER PANEL (REAR - MID & HIGH)

ACCESSORIES

050123	050154	050156	050147
UPPER PASSENGER PANEL (REAR - MID & HIGH)	SIDE PANEL (REAR - LOW ROOF)	SIDE PANEL W/ TRAY (REAR - LOW ROOF)	UPPER PASSENGER PANEL W/ TRAY (REAR - LOW ROOF)

050150	050128	050125	110064-P
UPPER DRIVER PANEL W/ TRAY (REAR - LOW ROOF)	UPPER DRIVER PANEL W/ TRAY (REAR - MID & HIGH)	UPPER PASSENGER PANEL W/TRAY (REAR - MID & HIGH)	PARTITION W/ DOOR (HIGH ROOF)

110061-P	110052-P	110049-P	110055-P
PARTITION W/ DOOR MID ROOF	PERFORATED WINDOW PARTITION (NO ACCESS - MID ROOF)	PERFORATED WINDOW PARTITION (NO ACCESS - LOW ROOF)	PERFORATED WINDOW PARTITION (NO ACCESS - HIGH ROOF)

INDEX

A

ABS SPEED SENSOR	3
A/C CONDENSOR	5
ALTERNATOR	7
AIR FILTER	8
AIR INTAKE HOSE	9
AIR CLEANER INTAKE TUBE	9
AIR DEFLECTOR (UPPER)	11
AMBER BULB (FRONT TURN MARKER)	13
AXLE BEAM DAMPER (REAR)	16

B

BRAKE PADS	3
BRAKE HARDWARE KIT	3
BRAKE LIGHT SWITCH	7
BUMPER FACIA (REAR)	10
BUMPER BRACKETS AND COVERS	11,12
BUMPER STEP BRACKET KITS	20
BUMPER REINFORCEMENTS	12
BACKUP CAMERA	14
BACKUP CAMERA MOUNT	14
BALL JOINT	16
BAR BUSHING (FRONT)	16
BEARING KIT (FRONT)	17

C

CALIPERS	3
CARGO LAMP KITS	20
COOLANT RESERVOIR	4
COOLANT MOTOR AND FAN ASSY	4
COOLANT THERMOSTAT HOUSING	4
CAMSHAFT SENSORS	7
COOLANT TEMPERATURE SENSOR	7
CONDENSER ASSY	5
CRANKSHAFT SEAL	9
CATALYTIC CONVERTERS	9
CARGO MAT	12
CONTROL ARMS	15
CONTROL ARM BOLT	15
COIL SPRING INSULATORS	16

D

DOOR HINGES	6
DOOR HANDLES	6
DOOR CHECKS AND COVER	6,7
DOOR HANDLE BEZEL	6
DOOR LOCK SWITCH	6

DOOR LATCH ASSY	6
DOOR WINDOW SWITCH	6
DASH CONTROL UNIT	6
DEFLECTOR	10
DOOR ROLLER	6
DOOR TRACK ASSEMBLY (UPPER)	6
DOOR WINDOW ASSEMBLY (RIGHT)	6
DOOR GLASS	12
DRIVE SHAFT COUPLING ASSY	17
DUST SHIELD COVER BOOT	15

E

ENGINE MOUNT	9
EXHAUST MANIFOLD GASKET	8
EXHAUST TAIL PIPE	9
EXHAUST MUFFLER	9

F

FRONT ROTOR HUB BOLT	4
FUEL INJECTOR	10
FUEL PUMP AND SENDER ASSEMBLY	10
FUEL TANK LOCK RING	10
FUEL PUMP RING GASKET	10
FENDER LINERS	11
FENDERS	11
FENDER BRACES	11

G

GRILLE MOUNTING PANEL	10
GRILLE REINFORCEMENT PANEL	10
GRAB HANDLE	20
GRIP STEPS	20

H

HYDRAULIC BRAKE HOSES	3
HEADLIGHT SWITCH	7
HEADLAMP ASSY	13
HEADLAMP BULBS	13
HOOD HINGES	11
HORN	7

I

INTERMEDIATE PARK BRAKE CABLE	3
IGNITION COIL	7
IGNITION KNOCK SENSOR	7
IGNITION SWITCH	7

INTAKE MANIFOLD GASKET	8
INNER TIE ROD	15
INNER TIE ROD BOOT	15
INVERTER CHARGERS	19

J

JUNCTION BLOCK	7
----------------------	---

K

KEY FOB TRANSMITTER	21
KEYLESS ENTRY LOCKS	21
KEYLESS MODULE	21

L

LEAF SPRING BRACKETS	16
LEAF SPRING SHACKLES	16
LICENSE PLATE BRACKET	12
LED FLOOD LIGHTS	19
LOADING RAMPS	19

M

MASTER CYLINDER	4
MASTER CYLINDER RESERVOIR	4
MASTER CYLINDER RESERVOIR CAP	4
MAXIFUSE ASSY (60/80/100/200 AMP)	7
MASS AIR FLOW SENSOR	9
MIRROR GLASS	14
MIRROR ASSEMBLIES	13
MIRROR COVERS	14

INDEX

O

OIL PAN (LOWER).....	8
OIL DRAIN PLUG.....	8
OIL FILTERS.....	8
OIL FILLER CAP.....	8
OXYGEN SENSORS.....	8
OIL PRESSURE SENSOR.....	9
OUTER TIE ROD.....	14

P

PARK BRAKE CABLES.....	3
PANELS.....	20,21
PARTITIONS.....	21
PIGTAIL.....	19
POWER BOOSTER.....	4
POWER WINDOW MOTORS.....	7
PVC VALVE.....	9
POWER HEATED MIRROR SIGNAL (LEFT).....	14
POWER STEERING PUMP.....	15
PRESSURE HOSE ASSY.....	15
POWER STEERING PRESSURE HOSE.....	15
POWER STEERING COOLER LINE.....	15
POWER STEERING RETURN HOSE ASSY.....	15
POWER STEERING COOLING COIL.....	15

R

ROTORS.....	3
RADIATORS.....	4
RADIATOR HOSES.....	4
RADIATOR SUPPORT.....	11
RADIATOR CAP.....	4
ROCKER PANEL MOULDING TRIP (RIGHT).....	11
REAR END BUMPER CAPS.....	10
RACK AND PINION GEAR.....	15
REAR SPRING.....	15
REAR SHOCK ABSORBER.....	16
REAR AXLE HUB NUT.....	18

S

SLIDING DOOR HANDLES.....	5,6
SLIDING DOOR ROLLER HINGES.....	6,7
SLIDING DOOR LOCK ACTUATOR (RIGHT).....	6
STARTER.....	7
SERPENTINE BELTS.....	8
SPARK PLUG.....	9
SUBFRAME BOLT (FRONT).....	11

STOP LAMP ASSY (HIGH - CENTER).....	13
SIDE MARKER BULB.....	13
SIDE MIRROR LAMPS.....	13,14
STEERING PUMP RESERVOIR.....	14
STEERING PUMP RESERVOIR CAP.....	14
STEERING KNUCKLE (LEFT).....	14
SUSPENSION STRUT MOUNT (UPPER).....	16
SUSPENSION STRUT (FRONT).....	16
SUSPENSION STRUT BUMPER.....	16
STABILIZER BAR (FRONT).....	16
STABILIZER BAR LINK (FRONT).....	16
STEEL WHEEL.....	17

T

THERMOSTAT.....	5
TEMPERATURE GASKET.....	5
TURN SIGNAL COMBO LEVER SWITCH.....	7
THROTTLE BODY AND MOTOR ASSY.....	10
TAILLAMP ASSY.....	13
TURN SIGNAL BULB (REAR).....	13
TRANSMISSION FILTER.....	17
TRANSMISSION MOUNT.....	17
TRANSMISSION FLUID.....	17
TPMS SENSOR.....	17
TRAILER HITCHES.....	19

U

UNIVERSAL JOINT.....	17
UNIVERSAL GRAB HANDLE.....	20

V

VALVE COVER GASKETS.....	8
--------------------------	---

W

WHEEL ASSY SENSOR (REAR).....	7
WATER PUMP.....	5
WATER PUMP GASKET.....	5
WINDSHIELD.....	10
WHEEL MOULDING DEFLECCORS.....	10
WINDOW REGULATORS.....	6
WHEEL LUG NUT.....	17
WHEEL HUB (REAR).....	17
WHEEL BEARINGS.....	17
WHEEL BEARING RACES.....	17,18
WINDSHIELD FLUID LEVER SENSOR GROMMET... ..	18
WINDSHIELD FLUID PUMP GROMMET.....	18
WINDSHIELD WIPER SWITCH.....	18

WIPER BLADES.....	18
WINDSHIELD FLUID RESERVOIR.....	18
WINDSHIELD FLUID RESERVOIR CAP.....	18
WINDSHIELD WASHER PUMP.....	18
WINDSHIELD FLUID LEVEL SENSOR.....	18

Order Online at:



FleetandAuto.com is operated by Jasper Innovative Solutions (JIS), a leading supplier of auto parts and components for fleet vehicles. JIS offers both premium aftermarket and OEM replacement parts from the brands you trust, as well as Heavy Duty alternatives designed in-house. JIS sources and produces parts that are no longer available from OEM suppliers to keep your vehicles running longer.



800-752-1700

WWW.FLEETANDAUTO.COM



Follow us on social media